



The phaser check is a pair of checks, back-to-back, with both poppets mechanically actuated. The valve is meant to be installed into the piston or rod of a cylinder. When the cylinder reaches the end of its stroke the poppet in the phaser check is shoved off its seat allowing flow through the piston. This allows two cylinders to get back into phase.

TECHNICAL DATA

NOTE: DATA MAY VARY BY CONFIGURATION. SEE CONFIGURATION SECTION.

Maximum Operating Pressure	350 bar
Maximum Valve Leakage at 110 SUS (24 cSt)	0,07 cc/min.
Valve Internal Hex Size	8 mm
Seal kit - Cartridge	Buna: 990162007
Seal kit - Cartridge	Polyurethane: 990162002
Seal kit - Cartridge	Viton: 990162006

NOTES

A special tool is required to install this cartridge. Use part number 998-101 to order this tool.

CONFIGURATION OPTIONS

Model Code Example: CDAQMCN

CONTROL	(M)	CRACKING PRESSURE	(C)	SEAL MATERIAL	(N)
M Mechanical Actuation		C 30 psi (2 bar)		N Buna-N	
				V Viton	