



The accumulator sense, pump unload pilot valve is used to sense pressure in an accumulator at port 1 of the valve and when the pressure at port 1 reaches the valve setting, port 2 connects to port 3 to vent a relief valve and unload the pump. This valve has a 20% ratio between unload setting and reset; when pressure at port 1 falls below 80% of the valve setting, port 2 is blocked from port 3 and the pump will come back online to recharge the accumulator.

This valve requires a separate check valve between port 1 and the pump. Another version of the accumulator sense, pump unload valve, QCDB, includes a free-flow check valve for pump flows under 12 gpm (50 L/min).

**TECHNICAL DATA**

NOTE: DATA MAY VARY BY CONFIGURATION. SEE CONFIGURATION SECTION.

Maximum Operating Pressure	350 bar
Pilot Flow Capacity	0,75 L/min.
Adjustment - No. of CW Turns from Min. to Max. setting	5
Locknut Hex Size	15 mm
Locknut Torque	9 - 10 Nm
Seal kit - Cartridge	Buna: 990011007
Seal kit - Cartridge	Polyurethane: 990011002
Seal kit - Cartridge	Viton: 990011006

**CONFIGURATION OPTIONS**

**Model Code Example: QPABLAN**

CONTROL	(L) ADJUSTMENT RANGE	(A) SEAL MATERIAL	(N) MATERIAL/COATING
<b>L</b> Standard Screw Adjustment	<b>A</b> 1000 - 3000 psi (70 - 210 bar), 1000 psi (70 bar) Standard Setting	<b>N</b> Buna-N	Standard Material/Coating
<b>C</b> Tamper Resistant - Factory Set	<b>B</b> 500 - 1500 psi (35 - 105 bar), 500 psi (35 bar) Standard Setting	<b>V</b> Viton	/LH Mild Steel, Zinc-Nickel
	<b>C</b> 2000 - 5000 psi (140 - 350 bar), 2000 psi (140 bar) Standard Setting		
	<b>D</b> 250 - 800 psi (18 - 55 bar), 250 psi (18 bar) Standard Setting		